


Model DLP-5.10

Part Number: 299-600-71 Rev. A


MCG Ethernet Surge Protector Installation Instructions

For 10BASE-T, CCTV, Token Ring, I/O Ports Applications



To Install:

1. Disconnect data cable from equipment and plug into BNC jack network ports.
2. Install BNC patch cable between protector ports and equipment to be protected.
3. Connect green ground wire (supplied) from ground post on protector to chassis of equipment to be protected.
4. For indoor use only.
5. Surge protectors should be installed in pairs (protector at each end of cable run) to protect the equipment at each end of the data cable.



SENTINEL POWER INC.

922 Middletown Rd, New Stanton, PA 15672

Email: ken@sentinelpower.com

Toll Free: 1-800-784-7989